



## **A Guide to Installing POI files for your TomTom Sat Navs.**

### **Step 1**

For Keyfuels and Shell customers call 01543 465739 or email [info@aidfuelcards.co.uk](mailto:info@aidfuelcards.co.uk) and we will send you the POI file.

Make a note where you download the POI files to as you will copy them across from this folder later.

### **Step 2**

Plug the TomTom into your USB. Once you have turned it on open 'My Computer' and you should see the TomTom drive.

### **Step 3**

Open the TomTom drive by double clicking on the icon. Identify the map folder.

### **Step 4**

Open the folder containing the POI. Select the files by clicking on them and copy and paste these to the map folder that you have located above.

### **Step 5**

To enable the new POI disconnect your TomTom from the computer and turn it on.

Go To:

- Change Preferences
- Manage POI
- Enable/Disable POI and scroll down and select your new POI.
- Click done and disconnect your TomTom.